





PROCESSOR
PCB
(3 DIAGRAMS)








OSCAR MIDI PCB.






UNMARKED POWER CONNECTIONS


74LS02 +5V Pin 14
74LS08 GND Pin 7

CONNECTIONS CARRIED VIA PROCESSOR PCB SOCKETS










3

NOISE GENERATOR & TRIGGER IN/OUT





4

